



European Network of
Transmission System Operators
for Electricity

BOUNDARY AND REFERENCE DATA EXCHANGE APPLICATION SPECIFICATION

2023-03-01

APPROVED DOCUMENT
VERSION 1.0

Copyright notice:

Copyright © ENTSO-E. All Rights Reserved.

This document and its whole translations may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, except for literal and whole translation into languages other than English and under all circumstances, the copyright notice or references to ENTSO-E may not be removed.

This document and the information contained herein is provided on an "as is" basis.

ENTSO-E DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

This document is maintained by the ENTSO-E CIM WG. Comments or remarks are to be provided at cim@entsoe.eu

NOTE CONCERNING WORDING USED IN THIS DOCUMENT

The force of the following words is modified by the requirement level of the document in which they are used.

- **SHALL:** This word, or the terms "REQUIRED" or "MUST", means that the definition is an absolute requirement of the specification.
- **SHALL NOT:** This phrase, or the phrase "MUST NOT", means that the definition is an absolute prohibition of the specification.
- **SHOULD:** This word, or the adjective "RECOMMENDED", means that there may exist valid reasons in particular circumstances to ignore a particular item, but the full implications must be understood and carefully weighed before choosing a different course.
- **SHOULD NOT:** This phrase, or the phrase "NOT RECOMMENDED", means that there may exist valid reasons in particular circumstances when the particular behaviour is acceptable or even useful, but the full implications should be understood and the case carefully weighed before implementing any behaviour described with this label.
- **MAY:** This word, or the adjective "OPTIONAL", means that an item is truly optional.

Revision History

Version	Release	Date	Paragraph	Comments
0.1	0	2022-01-31		Initial version
0.2	0	2023-02-15		Version for CIM WG review
1.0	1.0	2023-03-01		Approved document

34 CONTENTS

35	Copyright notice:.....	2
36	Revision History	3
37	CONTENTS	4
38	1 Introduction	6
39	1.1 Implementation in standards.....	7
40	2 Scope	7
41	3 Normative references	7
42	4 Terms and definitions.....	7
43	5 Abbreviated terms.....	8
44	6 Boundary datasets specification	9
45	6.1 Requirements	9
46	6.2 General concept	9
47	6.3 Data content.....	10
48	6.3.1 Header	10
49	6.3.2 Main data content.....	10
50	6.4 Data validation	23
51	7 Reference datasets specification	23
52	7.1 Requirements	23
53	7.2 General concept	23
54	7.3 Data content.....	24
55	7.3.1 Header	24
56	7.3.2 Main data content.....	24
57	7.3.3 Linkage between reference data instances and other data	
58	instances	26
59	7.4 Data validation	27
60	7.5 Data publication.....	27
61	7.6 Data serialisation.....	27
62	7.6.1 Data serialisation outlook	27
63	7.7 Data packaging.....	28
64	8 Implementation guidance	28
65	8.1 General.....	28
66	8.2 Examples on boundary datasets and reference datasets	28
67	8.2.1 Complete set which includes reference data	28
68	8.2.2 Separate boundary and reference datasets.....	28
69	8.2.3 Modular boundary set per MAS border and separate reference	
70	dataset	29
71	9 Bibliography	29
72	10 Annex A: Boundary point issue background	29
73		
74	List of figures	
75	Figure 1 Hierarchy of specifications and implementation guides.	6

76	Figure 2 Definitions as defined in IEC 60633	15
77	Figure 3 Boundary point connection cases	16
78	Figure 4 Boundaries for internal and external HVDC Links	16
79	Figure 5 Boundary with a single IGM, no duplication of boundary information	17
80	Figure 6 Boundary with two IGMs connected	18
81	Figure 7 Transfer capacity trade at boundary with two IGMs	18
82	Figure 8 Trade with at a boundary with single IGM	19
83	Figure 9 Injection model boundary with AC IGMs	20
84	Figure 10 Boundary for a DC IGM and AC IGMs in a CGM or a partial CGM	21
85	Figure 11 Boundary in a tie-line	22
86	Figure 12 Boundary point in a substation	22
87		
88	List of tables	
89	No table of figures entries found.	

1 Introduction

Boundary datasets use the definitions of boundary profiles (Equipment boundary, EQBD and Topology boundary, TPBD) defined in previous IEC CGMES versions. Starting with CGMES v3.0 of 2021, the TPBD profile has been discontinued, while the EQBD profile has been only deprecated – to allow for smooth transition to its new counterpart: simply the Core Equipment (Core EQ) profile. In other words, Core EQ profile is to be used as governing profile for boundary datasets for new developments, as it is covering a wider set of use cases, while the deprecated EQBD profile can still be used for a transition period.

There are additional needs for header and metadata information to support the addition Network Code services as Coordinated Security Analysis (CSA), Coordinated Capacity Calculation (CCC) and Outage Planning Coordination (OPC) that require usage of Common Grid Model (CGM). Therefore, ENTSO-E approved “Metadata and document header data exchange specification” to extend both CGMES v3 and IEC 61970-552:2016 (header part of the standard).

As part of the Network Code profile the Equipment Reliability are also included as part of the governing profiles for the boundary dataset.

In general, addition to the IEC standards (such as e.g. CGMES 3.0) or ENTSO-E specifications (such as, e.g., CSA profiles), there are three types of documents that should be considered when implementing these profiles.

- “Metadata and document header data exchange specification” (nickname “Header”) is an ENTSO-E specification describing the metadata and header data, which complements Network codes profiles (also sometimes referred to as CSA profiles)
- “Boundary and Reference data specification” (nickname “Boundary”) is this document, which extends CGMES (IEC 61970-600-1:2021 and IEC 61970-600-2:2021). It is at present an ENTSO-E specification, but will be integrated in the next edition of IEC CGMES standard, e.g. v3.1. It refers to “Metadata and document header data exchange specification” and it is to be applied in all CGMES v3 applications that need to support CGM process (perhaps TYNDP as well).
- Each business process, such as CSA, CC, OPC or TYNDP, creates Implementation guide (IG) that refers to header and boundary documents and describes how to use them for their own process. However, IG can only constrain and shall not extend or contradict other documents. The IGs are reviewed and agreed by CGMES SG and recommended to CIM WG.

The following figure illustrated the main documents.




Figure 1 Hierarchy of specifications and implementation guides.

1.1 Implementation in standards

This document contains specification and guidance related to boundary data and reference data. The intention is that the content is included in next revision of related standards. However, the standardisation process may take 1-2 years. Therefore, in the meantime, the approved version of this specification can be implemented and will be referenced from various implementation packages, e.g. a package that contains all relevant document for the implementation of processes such as CGM building process or TYNDP process.

In case an application (software) is used in multiple business processes which may require support of boundary datasets that are exchanged either in one or many instance files, this application should support all different ways specified in this document. This is also recommended practice to be able to transition to the new way of handling boundaries and reference data.

2 Scope

This document specifies improved handling of boundary and reference data. It defines the business constraints related to them. Therefore, it assumes that readers are familiar with related data exchange standards and either have or plan to have applications conform to data exchange standards prior implementing business constraints defined in this document.

3 Normative references

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

- IEC 61970-600-1:2021 Energy management system application program interface (EMS-API) - Part 600-1: Common Grid Model Exchange Standard (CGMES) - Structure and rules;
- IEC 61970-600-2:2021 Energy management system application program interface (EMS-API) - Part 600-2: Common Grid Model Exchange Standard (CGMES) - Exchange profiles specification.
- IEC 60633 Edition 2.1 Terminology for high-voltage direct current (HVDC) transmission

4 Terms and definitions

4.1

dataset

RDF(S)/OWL file that contains individuals that comply with the classes as specified by ontologies

[SOURCE: ISO 21597-1:2020, 3.1.10]

4.2

model

collection of data describing instances, objects or entities, real or computed. In the context of CIM the semantics of the data is defined by profiles. Hence a model can contain equipment data, power flow initial values, power flow results etc.

Note 1 to entry: In power system analysis, a model is a set of static data describing the power system. Examples of Models include the Static Network Model, the Topology Solution, and the Network Solution produced by a power flow or state estimator application.

[SOURCE: IEC 61970-552:2016, 3.8]

169 **4.3**
170 **modelling authority set**
171 an abstract entity which is attributed to an agent (modelling authority). The modelling authority
172 set is versioned by the agent.

173 **4.4**
174 **modelling authority set version**
175 a specialization of the modelling authority set which is attributed to an agent. A version of the
176 modelling authority set can be seen as an envelop for models which conform to different
177 profiles.

178 **4.5**
179 **model exchange**
180 the storing, accessing, transferring, and archiving of models

181 **4.6**
182 **profile**
183 schema that defines the structure and semantics of a model that may be exchanged

184 Note 1 to entry: A Profile is a restricted subset of the more general CIM.
185 [SOURCE: IEC 61970-552:2016, 3.9]

186 **4.7**
187 **profile document**
188 collection of profiles intended to be used together for a particular business purpose
189 [SOURCE: IEC 61970-552:2016, 3.10]

190 **5 Abbreviated terms**

191	CIM	Common Information Model (electricity)
192	CGMES	Common Grid Model Exchange Standard
193	CGM	Common Grid Model
194	DSO	Distribution System Operator
195	ENTSO-E	European Network of Transmission System Operators for Electricity
196	IEC	The International Electrotechnical Commission
197	IGM	Individual Grid Model
198	SO	System Operator
199	MAS	Model Authority Set
200	NC	Network codes
201	RDF	Resource Description Framework
202	RDFS	RDF Schema
203	SHACL	Shapes Constraint Language
204	TSO	Transmission System Operator
205	URI	Uniform Resource Identifier
206		

6 Boundary datasets specification

6.1 Requirements

IGMs and CGMs need to support multiple processes which requires the following additional information and general terms:


- usage of reference data;
- support of boundary point in a substation which also needs to take into account boundary point setup for HVDC interconnections;
- full coverage of TSO-DSO data exchange which requires new boundary considerations.

6.2 General concept

The following additional requirements are defined:

- Boundary datasets are bilateral, i.e. agreed between entities connected or responsible for the boundary elements between them. Boundary datasets can be exported:
 - o per two MAS (e.g. TSO) border,
 - o per MAS (e.g. TSO),
 - o per region (e.g. Continental Europe, Nordic, pan-European, etc).

The following figure is illustrating different split options for the boundary dataset. In option a) there are four boundary instance files for each of the borders; in option b) there is one boundary set which covers all borders; in option c) each TSO has separate boundary dataset. There is no overlap between boundary information in option a) and b), while in option c) the boundary information between two MAS (TSOs) is duplicated. Option c) is only useful when for instance TSO A exchanges its boundary with the DSOs. However, this can also be achieved in similar manner using option a).



Option a) per border

Option b) per region

Option c) per TSO

- The versioning of the boundary sets is per collection, i.e. a set of per two MAS border, per MAS (e.g. TSO) or mixed exports of boundary datasets. There could be duplications between boundaries part of the set (export), but all boundary information shall be consistent and provided as a package or one or many datasets, i.e. it is not allowed for a package to include different versions of boundary datasets, e.g. pan-European boundary set valid for Jan 2023 cannot be package together with pan-European boundary set valid for Jan 2021.
- The tools shall be able to import multiple boundaries as a set (the package of which is versioned).

- 240 - A boundary dataset shall contain all containers that are shared between two
- 241 neighbouring MAS. Therefore, SubGeographicalRegion and GeographicalRegion shall
- 242 be defined in the reference data and shall not be redefined in a boundary set.
- 243 - No individual instance dataset can include duplicates. Network model management tools
- 244 and merging tools shall support duplicates existing in IGMs coming from (also defined
- 245 in) boundary and reference data. If there are duplicates, they shall be defined in
- 246 reference or boundary data. Duplication of any other non-boundary related information
- 247 is not allowed.
- 248 - Merged instance dataset shall not have any duplicates that were there for the purpose
- 249 of a pre-merge process. However, the application may need to keep track on the
- 250 duplications in order to be able to support disassembling process.
- 251 - BoundaryPoint-s shall be kept in a merged model to support disassembly.
- 252 - Each HVDC Pole has two BoundaryPoint-s. Depending on the HVDC modelling the
- 253 following exports/imports shall be supported:
 - 254 ○ An exporting party shall support one or more of injection models in their AC IGM
 - 255 and may also export DC IGMs.
 - 256 ○ An importing party shall support all the injection models in the AC IGMs and may
 - 257 also support import of DC IGMs.
- 258 - The modelling authority governing the boundary dataset and the version of the modelling
- 259 authority set providing the boundary dataset depends on the scope of the exchange
- 260 supported by the boundary dataset. In some cases, the modelling authority can be an
- 261 organisation like ENTSO-E and in other cases it could be an entity (e.g. system
- 262 operator) that manages a local boundary dataset, e.g. boundary dataset between a TSO
- 263 and DSOs.

264

265 **6.3 Data content**

266 **6.3.1 Header**

267 The document “Metadata and document header data exchange specification” describes the

268 header that accompanies the boundary datasets as well as the packaging and linking the data

269 via a manifest instance file.

270 **6.3.2 Main data content**

271 **6.3.2.1 Amendments to IEC 61970-600-1:2021**

272 The following amendments are applied to existing rules and constraints in CGMES v3:

- 273 • The standard shall specify that:
 - 274 ○ Equipment profile data can be exchanged together with Equipment Reliability
 - 275 profile (part of NC profiles) in one instance file.
 - 276 ○ Steady State Hypothesis profile data can be exchanged together with Steady
 - 277 State Instructions profile (part of the NC profiles) in one instance file.
- 278 • In addition, the following table provides some detailed changes.

279

Reference	Old text	New text	Status, justification
EQBD2	The equipment boundary profile defines which instance data represents types or voltages which are agreed for the CGMES based exchanges. Therefore, individual grid models shall refer to the equipment boundary instance file to use declared EnergySchedulingType-s, GeographicalRegion-s (EQ__4 does not apply for equipment boundary profile and instance data) and BaseVoltage-s. This does not limit different model authorities when it comes to defining additional types or voltages in their instance files (distribution), although there shall not be an overlap of data values between equipment boundary files and individual grid model instance files.	Left blank intentionally.	deleted as reference data instance is not included in the boundary dataset
FILX3	One zip file may only contain the following types of files: – A single instance file (distribution) of the following types: equipment (EQ), equipment boundary (EQBD), topology (TP), steady state hypothesis (SSH), state variables (SV), dynamics (DY), diagram layout (DL), geographical location (GL). – Combinations of equipment, topology, steady state hypothesis, state variables, dynamics, diagram and geographical instance files which are allowed by the CGMES and are related to one MAS only.	One zip file may only contain the following types of files: – A single XML instance file (distribution). – Multiple XML instance files that are related to one or more MAS. – Difference XML files of one or more MAS. – Boundary MAS XML instance files (full or difference) - Reference instance data – one or many XML instance files	

	– Difference files of one MAS. – Equipment, topology, steady state hypothesis, state variables, dynamics, diagram and geographical files per MAS for an merged model. – Difference files per MAS for an merged model. – Boundary MAS instance files (full or difference if the merged model is expressed with difference files) shall always be included in the zip file containing an merged model		
BPPL5	There are two main representations/exchanges of an HVDC link which are supported by the CGMES: – Simplified exchange (no exchange of the AC/DC part of the HVDC interconnections. A HVDC link is represented with two radial AC lines). – Detailed exchange (AC/DC part of HVDC links is exchanged).	replaced by the information in section “HVDC modelling alternatives”	
BBPL6	In the simplified exchange of an HVDC link the net interchange between the MAS is represented by EquivalentInjection classes referring to each common coupling node (CC).	For an HVDC link (modelled as simplified or detailed) the net interchange between the MAS-s is represented by EquivalentInjection classes referring to each common coupling node (CC), i.e. the BoundaryPoint.	Modified. The point of common coupling for an ACDCCConverter is a Terminal connected to the BoundaryPoint.
BPPL8	In the detailed exchange of an HVDC link the HVDC grid shall be exchanged as a MAS: – Separate instance files (EQ, TP, SSH, SV) are	In the detailed exchange of an HVDC link the HVDC grid shall be exchanged as a MAS: – Separate instance files (EQ, TP, SSH, SV) are included in an HVDC MAS, or	Modified. It is allowed business processes to restrict detailed HVDC MAS to be exchanged separately also if it is part of

	included in a HVDC MAS, or – In case one system operator (TSO or DSO) is responsible for the HVDC, the HVDC model is included in the system operator MAS (EQ, TP, SSH, SV).	– In case one system operator (TSO or DSO) is responsible for the HVDC, the HVDC model can be included in the system operator MAS (EQ, TP, SSH, SV).	internal to the MAS grid.
BPPL9	In case of a detailed exchange of an HVDC link, the HVDC MAS shall refer to the common coupling points (ConnectivityNode) included in the Boundary set.	In case of a detailed exchange of an HVDC link, the HVDC MAS shall refer to the common coupling points (ConnectivityNode) associated with a BoundaryPoint. ACDCCConverter.PccTerminal shall be a Terminal that is connected to a BoundaryPoint	Modified
BPPL12	The objective of this version of the CGMES is to enable a possibility to make a bilateral agreement based on the EQ profile vocabulary. The reason for this is that the content of the boundary can be different among different business processes. The recommendation is that the agreement is as minimalistic as possible preferably just a ConnectivityNode. For instance, the boundary data set of IEC 61970-600-2 are considered to meet this requirement. It is recommended that model parts intended for model assembly do not contain boundary information, i.e. no overlap of data between model parts and boundary instance files.	The objective of this version of the CGMES is to enable a possibility to make a bilateral agreement based on the EQ profile vocabulary. The reason for this is that the content of the boundary can be different among different business processes. The recommendation is that the agreement is as minimalistic as possible preferably just a ConnectivityNode. For instance, the boundary dataset of IEC 61970-600-2 are considered to meet this requirement.	
PROF10	CGMES instance file (distribution) dependency shall be declared by md:Model.DependentOn in the header according to Figure 1 and the associated rules.	CGMES instance file (distribution) dependency shall be declared by md:Model.DependentOn (prov:Model.wasInfluencedBy in the new header) in the header according to Figure 1 and the associated rules.	

	Rules: - Diagram Layout [DL] shall be associated with one or more in {Core Equipment [EQ], Topology [TP], Dynamics [DY]} - Geographical Location [GL] shall be associated with one or more in {Equipment Boundary [EQBD], Core Equipment [EQ]} - Topology [TP] shall be associated with one or more Steady State Hypothesis [SSH]. The cardinalities of dependencies shown in Figure 1 are the minimum requirement. It is allowed, but not required, to include indirect references (references made by the referred instance file). It is expected that by including all instance files defined in the DependentOn references and the referred files DependentOn there shall not be any dangling references (e.g. no object is pointing to a non-existing object in the assembled or merged model).	Rules: - Diagram Layout [DL] shall be associated with one or more in {Core Equipment [EQ], Topology [TP], Dynamics [DY]} - Geographical Location [GL] shall be associated with one or more in {Equipment Boundary [EQBD], Core Equipment [EQ]} - Topology [TP] shall be associated with one or more Steady State Hypothesis [SSH]. References to used reference data shall be provided. The cardinalities of dependencies shown in Figure 1 are the minimum requirement. It is allowed, but not required, to include indirect references (references made by the referred instance file). It is expected that by including all instance files defined in the DependentOn references and the referred files DependentOn there shall not be any dangling references (e.g. no object is pointing to a non-existing object in the assembled or merged model).	
--	--	---	--

280

281 6.3.2.2 Boundary point for HVDC interconnection

282 The concept of an HVDC Pole is defined in IEC 60633 and is shown in Figure 2.




Figure 2 Definitions as defined in IEC 60633

In this document item 8.5 “HVDC system pole” in Figure 2 is called an “HVDC Pole”, not an “HVDC system pole”. Each HVDC Pole has a boundary point at each side which means two boundary points per HVDC Pole as shown by the red circles in Figure 2. Figure 2 also shows the point of common coupling (PCC) at “A” but the branches from the PCC to the HVDC Poles is not shown with enough detail to indicate the locations of the PccTerminals. The PccTerminal is shown in Figure 3, which illustrates the connection mechanism of IGMs via boundary points that follows the process defined in CGMES.




Figure 3 Boundary point connection cases

The left case in Figure 3 shows an AC IGM that is not connected to the DC IGM at the other side. The middle case shows a DC IGM that is not connected to the AC IGM at the other side, this happens when a DC IGM has HVDC Poles with only one end connected. The right case shows a situation where the DC and AC IGMs are connected.

Figure 4 illustrates an HVDC Bipole, where the upper part in the figure shows an external HVDC Link between TSOs and the lower - an internal HVDC Link.




Figure 4 Boundaries for internal and external HVDC Links

304 A consequence of having the filters in the AC IGM is that the shunts and filters will be described
305 in two different AC IGMs for an external HVDC Link. In case the TSO responsible for the link
306 would like to manage the filters at both sides of the HVDC Link, all filters can be moved into the
307 AC IGM of the TSO managing the HVDC Link. This is accomplished by making the HVDC Link
308 internal to the TSO IGM and introducing an AC boundary as shown to the right in Figure 4.


309 Detailed models for HVDC Links embedded in an AC IGM may be provided by the responsible
310 TSO as a service to other TSOs or RCCs. Using detailed HVDC models means including DC
311 IGMs in the assembly of a CGM.

312 All BoundaryPoint-s are defined for the AC part of the grid even if they need to be used for
313 connecting with DC IGM.

314 6.3.2.3 Boundary connectivity

315 6.3.2.3.1 Incomplete connectivity at boundary

316 In case boundary information is not duplicated in an IGM, this IGM is incomplete and a power
317 flow cannot be computed with an IGM alone. By assembling an IGM with the boundary, the IGM
318 becomes complete and power flow can be computed. This boundary situation is shown in Figure
319 5.



320

321 Figure 5 Boundary with a single IGM, no duplication of boundary information

322 The IGM connects to a TopologicalNode and a ConnectivityNode with a Terminal belonging to
323 one branch, typically a ACLineSegment, and one EquivalentInjection in case of AC
324 interconnection on a Line. The EquivalentInjection's Terminal has a SvPowerFlow.

325 6.3.2.3.2 Complete connectivity at boundary

326 A model having two IGMs connecting at a boundary is shown in Figure 6.




Figure 6 Boundary with two IGMs connected

Each IGM connects to the Boundary (TopologicalNode and ConnectivityNode) using the Terminal-s of the related equipment. In case of AC interconnection on a Line as shown in Figure 6, a ACLineSegment and one EquivalentInjection. The EquivalentInjection's Terminal has a SvPowerFlow.

The sum of the power flows in EquivalentInjection-s (EI1 and EI2) are supposed to be equal with different signs but as this typically is not the case at initial IGM delivery, they shall be aligned as part of the CGM creation process.

6.3.2.4 Control area conventions

When a tie line, e.g. a `ACLineSegment`, is connected to a boundary which is also a boundary for a `ControlArea` of type `interchange` (`ControlArea.type` equals `ControlAreaTypeKind.Interchange`) it may have a `TieFlow`. If a tie line is included in transfer capacity trade it shall have a `TieFlows` as shown in Figure 7.




Figure 7 Transfer capacity trade at boundary with two IGMs


The flows at Terminal-s (e.g. SvPowerFlow) follow the load sign convention, i.e. flow from the TopologicalNode into the Terminal is positive. This means that a power flow at a tie line connected to a boundary TopologicalNode (TN) is a flow into the ControlArea. Figure 7 shows

346 an example where the dashed arrow represents a flow into the ControlArea and the ACLS1
347 Terminal, shown with green in Figure 7, has a positive flow which is the same sign convention
348 as for ControlArea.netinterchange.

349 The calculated power flow for the tie line is updated at the SvPowerFlow at the
350 EquivalentInjection. Figure 7 shows a SvPowerFlow linked to the EI1 Terminal, yellow in Figure
351 7. The flow at the EI1 Terminal is into the TN which is the negated value of the tie line flow.

352 The flag TieFlow.positiveFlowIn is true if the flow from the TN into the tie line Terminal, green
353 in Figure 7, is also a flow into the ControlArea. But with the conventions in Figure 7 where the
354 TieFlow is located at the tie line end towards the boundary and the SvPowerFlow is at
355 EquivalentInjection the TieFlow.positiveFlowIn being located at the tie line Terminal has lost its
356 meaning.

357 For trade with an IGM not included in the CGM a TieFlow is still present at the boundary
358 TopologicalNode / ConnectivityNode but no tie line will be connected for the not included IGM,
359 see Figure 8.



360

361


Figure 8 Trade with at a boundary with single IGM

362 The EquivalentInjection.p value, see dashed double arrow in Figure 8, describes the flow to or
363 from the not included IGM and must have a realistic value which is the reasoning in case of
364 partial merge for scaling the boundary injections (of the tie lines which are only defined on one
365 side and for which a TieFlow exists) to match the net interchanges.

366 6.3.2.5 HVDC modelling alternatives

367 6.3.2.5.1 Injection models without the DC IGM

368 The injections models without DC IGM apply to the AC IGMs only.



 Boundary point; a pair of `cim:Connectivity(CN)/cim:TopologicalNode(TN)`

Figure 9 Injection model boundary with AC IGMs

Figure 9 shows how two AC IGMs connect with an HVDC Link. At each side there is one `cim:EquivalentInjection`, EI1 and EI2, that describe the power flow into the HVDC Pole represented by the `cim:Line`. Note that `cim:DCLine` cannot be used as the `cim:DCLine` can only contain DC elements.

6.3.2.5.2 PQ Injection model without voltage control

Each side of an HVDC Pole is described by a `cim:EquivalentInjection` without voltage control (constant PQ element) in an AC IGM and without filters and shunts. It is used with CSC. This is a simplified HVDC model that shall not be combined with a DC IGM as the filters are missing and shall only be used if the intent is to never assemble the AC IGM with a matching DC IGM.

The reactive power in `cim:EquivalentInjection.q` corresponds to the reactive power consumed by the converter when the case was set up and changes in active power transfer due to contingencies is not reflected by a change in `cim:EquivalentInjection.q`.

6.3.2.5.3 PV Injection model with voltage control

Each side of an HVDC Pole is described by a `cim:EquivalentInjection` (EI) with voltage control in an AC IGM. This is a simplified HVDC model that can be assembled with a matching DC IGM.

The model uses simplified HVDC without shunts or filters. The voltage control gives a continuous response that does not match the discrete response of the shunts and filters from a CSC but describes the behaviour of a VSC well. As the `cim:EquivalentInjection` may also have a reactive capability curve it is used to describe the reactive power capability.

When this alternative is used at least the `cim:EquivalentInjection.minQ` and `cim:EquivalentInjection.maxQ` limits must be provided and the limit values shall match the reactive capability available at the active power flow specified in `cim:EquivalentInjection.p`.

This option can be used for

- simplified model of CSC where the shunts and filters are not modelled in the AC IGM. Instead, the `cim:EquivalentInjection` in the AC IGM has voltage control enabled to describe the absent filters. This model is not allowed as it is not representing the behaviour of the filter correctly. If a DC IGM exists use option 6.3.2.5.4.
- simplified model of VSC. This model can be assembled with a DC IGM as the `cim:EquivalentInjection-s` are replaced by the VSC in the DC IGM.

6.3.2.5.4 PQ Injection model with shunts and filters for voltage control

Each side of an HVDC Pole is described by a `cim:EquivalentInjection` without voltage control in an AC IGM and with shunts and filters in the AC IGM doing voltage control. It is used with CSC and is a simplified HVDC model that can be assembled with a matching DC IGM.

404 The filters not used for harmonics are available for voltage control. The `cim:EquivalentInjection`
405 is a constant PQ element.

406 A change in the active power transfer is handled as follows:


- 407 • `cim:EquivalentInjection.p` is updated.
- 408 • `cim:EquivalentInjection.q` may be updated to reflect the change in active power transfer,
409 e.g. by using the simple formula $Q=P/2$ or $Q=0.6*P$ according to some references. The
410 choice shall be based on the specific converter characteristics.
- 411 • The shunts and filters not used for harmonics filtering are available for voltage control.

412 This option supports DC IGMs with CSCs that are assembled into a CGM but can also be used
413 without the DC IGM.

414 6.3.2.5.5 Detailed representation with DC IGM

415 A DC IGM has a detailed model that describes the converters (CSC or VSC) for all HVDC Poles
416 in one HVDC Link. A TSO exporting a DC IGM will also export an AC IGM that connects with at
417 least one end of the HVDC Poles in the DC IGM. The other end of the HVDC Poles shall also
418 connect to an AC IGM.

419 As a DC IGM on its own is meaningless, an importing party must create a CGM including both
420 DC and AC IGMs. For a party importing a DC IGM this means that at least one AC IGM, that
421 connects with the HVDC Poles in the DC IGM, shall also be imported.



422

423 **Figure 10 Boundary for a DC IGM and AC IGMs in a CGM or a partial CGM**

424 Figure 10 shows two cases, the upper where the DC IGM is connected at one end of an HVDC
425 Pole and the lower where both ends of an HVDC Pole is connected to AC IGMs.

426 For an external link between two TSOs, an importing party shall include the AC IGM at least at
427 one end of the HVDC Poles in the DC IGM. With one end of the HVDC Poles connected to an
428 AC IGM and the other end not connected corresponds to the upper part of Figure 10. This is
429 useful when the CGM or a partial CGM is used in studies where active power losses are
430 considered but the voltage at the open end is not considered. In system studies where the

voltage is a concern as well as the power flow in a larger region the AC IGMs at both ends of the HVDC Poles shall be included in the CGM or a partial CGM which corresponds to the lower part of Figure 10.

In case of a CSC the filters shall be represented by the AC IGMs at both ends of the HVDC Poles.

6.3.2.6 Boundary point in a tie-line

Figure 11 shows the setup in case of BoundaryPoint in a tie-line.




Figure 11 Boundary in a tie-line

In the case of boundary point located in a tie-line, the container is a Line. The Line, the ConnectivityNode, EquivalentInjection-s and the ACLineSegment-s (ACLS1 and ACLS2) are included in the boundary.

6.3.2.7 Boundary point in a substation

Figure 12 shows the setup in case of BoundaryPoint in a substation.




Figure 12 Boundary point in a substation

There are three MAS-es representing IGMs and two boundary parts, one between MAS1 and MAS3 (MAS1-MAS3) and another one between MAS2 and MAS3 (MAS2-MAS3). Following the principle of duplicating data between IGM MAS and Boundary MAS defined in this document, the voltage levels, substation objects and any other common objects are included in the boundary MAS and neighbouring MAS-es. For instance, EI4 (EquivalentInjection), switches and disconnectors in MAS3 are contained in Bay C and VoltageLevel C and Substation 2. The BusbarSection, the BoundaryPoint, in Boundary MAS2-MAS3 are also contained in Bay C, VoltageLevel C and Substation 2. The same for EI2 and related switches and disconnectors in MAS2.

In case of more complex boundary additional elements can be included and if necessary additional boundary points are defined.

Note that not all terminals are shown in the figure illustrating boundary point in a substation.

6.4 Data validation

SHACL based constraints are used for the validation of boundary datasets. The constraints cover cardinality of attributes, datatypes, and any other complex dependencies.

The following constraints are defined in addition to other boundary related constraints:

- C:600:EQ:BoundaryPoint:HVDC

In case BoundaryPoint-s of an HVDC interconnection have to be modelled as BoundaryPoint-s in an AC Line instead of in a Substation, the two BoundaryPoint-s shall be contained in a single AC Line.

- C:600:EQ:BoundaryPoint:HVDCbipole

HVDC Bipole shall be modelled with four boundary points and each of the two HVDC Poles are modelled by an AC Line in cases where another container is not existing. Each HVDC Pole in an HVDC Bipole will have its own pair of PccTerminal-s.

7 Reference datasets specification

7.1 Requirements

When exchanging data there is a need to refer to common objects that are relevant for multiple data exchange processes. Having a mechanism to use a set or different sets of reference data would optimize the data exchange. For instance, CGMES equipment profile is defining BaseVoltage class and it is allowed that a given MAS is either referring to an instance of BaseVoltage defined by the MAS or by the Boundary MAS. However, Boundary profiles are deprecated in CGMES v3.0 and in addition there are new profiles that can benefit by using other reference data. Therefore, there should be a specification how to define and maintain reference data and how to include it in an exchange process.

7.2 General concept

The following specification is defined for supporting reference data:

- Reference data uses W3C ontologies such as
 - DCAT (W3C Data Catalog Vocabulary) is an RDF vocabulary designed to facilitate interoperability between data catalogs published on the Web. By using DCAT to describe datasets in catalogs, publishers increase discoverability and enable applications to consume metadata from multiple catalogs. It enables decentralized publishing of catalogs and facilitates federated dataset search across catalogs. Aggregated DCAT metadata can serve as a manifest file to facilitate digital preservation.

- 492 ○ SKOS (W3C Simple Knowledge Organization System) designed for

493 representation of thesauri, classification schemes, taxonomies, subject-heading

494 systems, or any other type of structured controlled vocabulary. SKOS is part of

495 the Semantic Web family of standards built upon RDF and RDFS, and its main

496 objective is to enable easy publication and use of such vocabularies as linked

497 data.
- 498 ○ CIM profiles that define classes that can be used for instantiating reference data.
- 499 • Reference data will be published following the principles of linked data, but in order to

500 manage the transition smoothly, sets of reference data can be made available for data

501 exchange processes and the implementation of this needs to be elaborated.
- 502 • In contrast to the current practice, reference datasets are packaged in separate, non-

503 boundary sets. These reference datasets are referenced from different models. For

504 instance, an IGM will need access to reference data for BaseVoltage, region definitions,

505 detail information on metadata, etc. Boundary Set will also need access to reference

506 data for elements that are common.
- 507 • The dependencies and packaging of the reference data is described in a manifest that

508 uses DCAT, see “Metadata and document header data exchange specification”.

509 7.3 Data content

510 Reference datasets can be grouped in two main categories:

- 511 • Datasets that include definitions of SKOS and DCAT vocabularies
- 512 • Datasets that do not include SKOS and DCAT vocabularies and are only based on parts
- 513 of the CIM model.

514 It is expected that at later stage all reference data will include elements of SKOS and DCAT

515 vocabularies which is also the way European Commission is publishing [authority tables](#).

516 Therefore, depending on the development stage different datasets can have different content

517 that is gradually aligned helping the transition to fully aligned reference data.

518 This section explains different options on the content of reference datasets and rules that are

519 used when converting the data from various sources. The explanation is mainly done using

520 examples.

521 7.3.1 Header

522 The document “Metadata and document header data exchange specification” describes the

523 header that accompanies the reference data as well as the packaging and linking the data via

524 a manifest instance file.

525 7.3.2 Main data content

526 Different instances of reference data build the main content of the dataset. Due to agreed

527 concepts at European level the current reference datasets distributions include only one

528 skos:ConceptScheme. For instance, if the dataset defines the reference data for BaseVoltage

529 the instance file which is a distribution of this dataset contains only one skos:ConceptScheme

530 `rdf:about=http://energy.referencedata.eu/BaseVoltage`.

531 The content of the skos:ConceptScheme provides the main information on the reference

532 dataset. The skos:ConceptScheme of reference power flow settings is provided for illustration.

```

533 <skos:ConceptScheme rdf:about="http://energy.referencedata.eu/PowerFlowSettings">
534   <rdf:type rdf:resource="http://www.w3.org/ns/dcat#Dataset"/>
535   <dcterms:modified>2022-09-16T13:18:37.985254</dcterms:modified>
536   <dcat:version>1</dcat:version>

```



```

537     <skos:prefLabel>PowerFlowSettings</skos:prefLabel>
538     <dcterms:identifier>urn:uuid:aaed01a1-fff7-49aa-a5f2-df07c05e16a9</dcterms:identifier>
539     <dc:keyword>PFS</dc:keyword>
540     <skos:definition xml:lang="en">List of commonly used Power Flow Settings</skos:definition>
541 </skos:ConceptScheme>

```

In fact the skos:ConceptScheme is describing the list, the group of reference data type. skos:Concept is used to define individual members of the list. The usage of SKOS allows to make relation between different skos:Concept-s which is necessary in some case. For instance a property like skos:exactMatch indicates that there is exact match between the skos:Concept defined in this dataset and another skos:Concept defined in another dataset. The example below shows the exact match relationship between the reference data on confidentiality level Sensitive which is defined by ENTSO-E and by the European Commission. Using this approach ENTSO-E can define a list of allowed confidentiality levels based on internal security related agreements and for some of confidentiality levels can reuse already defined levels by the EC, e.g. "Sensitivity".

```

552     <skos:Concept rdf:about="http://energy.referencedata.eu/Confidentiality/c28079e4-02ba-4a08-
553 9093-8247ebe57f21">
554     <dcterms:identifier>urn:uuid:c28079e4-02ba-4a08-9093-8247ebe57f21</dcterms:identifier>
555     <skos:prefLabel>Sensitive</skos:prefLabel>
556     <skos:definition xml:lang="en">Sensitive non-classified (SNC) information, information
557 whose unauthorised disclosure could cause damage to the Commission or other interested parties
558 such as businesses, companies, intellectual property or personal data but which is not EU
559 classified information.</skos:definition>
560     <skos:inScheme rdf:resource="http://energy.referencedata.eu/Confidentiality"/>
561     <skos:topConceptOf rdf:resource="http://energy.referencedata.eu/Confidentiality"/>
562     <skos:exactMatch rdf:resource="http://publications.europa.eu/resource/authority/access-
563 right/SENSITIVE"/>
564 </skos:Concept>

```

In general skos:Concept rdf:about shall be a resolvable URL. ENTSO-E is in transition to ensure this. There are two ways how the resolvable URL are formatted:

- {the URL for the ConceptScheme}/{the name of the Concept}

```

568 <skos:Concept rdf:about="http://energy.referencedata.eu/StandardBusinessTypeList/A01">

```

- {the URL for the ConceptScheme}/{the identifier of the Concept}

```

570 <skos:Concept rdf:about="http://energy.referencedata.eu/Confidentiality/c28079e4-02ba-4a08-
571 9093-8247ebe57f21">

```

Or

```

573 <skos:Concept
574 rdf:about="http://energy.referencedata.eu/BaseVoltage/6d63ed36bf6842f3b98995e04eed3dd0">

```

In most of the cases this is done to ensure a level of backwards compatibility. The general rule is that the URI used as rdf:about shall not be understood as a coded string from which information is derived. The purpose is to provide a reference to the data. Individual information is collected from the properties of the skos:Concept. The following instance of BaseVoltage reference data illustrates this.

```

580     <skos:Concept
581 rdf:about="http://energy.referencedata.eu/BaseVoltage/7891a026ba2c42098556665efd13ba94">
582     <rdf:type rdf:resource="http://iec.ch/TC57/CIM100#BaseVoltage"/>
583     <cim:BaseVoltage.nominalVoltage>220</cim:BaseVoltage.nominalVoltage>
584     <cim:IdentifiedObject.name>AC-220</cim:IdentifiedObject.name>
585     <cim:IdentifiedObject.description>Base voltage defined by ENTSO-E 220
586 kV</cim:IdentifiedObject.description>
587     <dcterms:identifier>urn:uuid:7891a026ba2c42098556665efd13ba94</dcterms:identifier>
588     <skos:prefLabel>AC-220</skos:prefLabel>
589     <skos:definition xml:lang="en">Base voltage defined by ENTSO-E 220 kV</skos:definition>
590     <skos:inScheme rdf:resource="http://energy.referencedata.eu/BaseVoltage"/>

```

```
591 <skos:topConceptOf rdf:resource="http://energy.referencedata.eu/BaseVoltage"/>
592 </skos:Concept>
```

593 Here skos:Concept includes properties that are native for the skos:Concept as well as CIM
594 attributes native to the cim:BaseVoltage. The class with rdf:about
595 http://energy.referencedata.eu/BaseVoltage/7891a026ba2c42098556665efd13ba94 has two
596 rdf:type-s skos:Concept and cim:BaseVoltage. Information is duplicated between some of the
597 properties CIM, SKOS, DCAT in order to facilitate transition period. After all systems transition
598 to be able to use SKOS and DCAT properties, the CIM properties can be removed.

599 The properties skos:inScheme and skos:topConceptOf are necessary to link the skos:Concept
600 to skos:ConceptScheme. skos:topConceptOf is a property that is used by the European
601 Commission in various tooling to help representing hierarchy of the skos:Concept. Therefore
602 skos:topConceptOf should be seen as part of the long term plan to align with EU Commission
603 Data Publication office practices and this is needed for VockBench (Tool that Data Publication
604 office is using) to show and display data in a correct way.

605 Note that the UUID "7891a026ba2c42098556665efd13ba94" is missing the "-" part of the
606 formatting, which is not correct. Also it would not be correct if the UUID
607 is "urn:uuid:_7891a026ba2c42098556665efd13ba94" as in this option is "_" should not be used.
608 The correct dcterms:identifier is:

```
609 <dcterms:identifier>urn:uuid:7891a026-ba2c-4209-8556-665efd13ba94</dcterms:identifier>
```

610 ENTSO-E CIM WG agreed to add additional entries of reference data with correct IDs that will
611 replace entries with not valid IDs. This is done in order to ensure transition.

612 7.3.3 Linkage between reference data instances and other data instances

613 There are two ways how to reference (link) to reference data.

- 614 • By using the identifier (dcterms:identifier)
- 615 • By using the complete URI/URL defined in the rdf:about of the skos:Concept

616 In Network Codes profiles approved by ENTSO-E and in CGMES, references on class level are
617 using rdf:resource as illustrated below.

```
618 <cim:ACLineSegment rdf:ID="_17086487-56ba-4979-b8de-064025a6b4da">
619   <cim:IdentifiedObject.name>BE-Line_1</cim:IdentifiedObject.name>
620   ...
621   <cim:ConductingEquipment.BaseVoltage rdf:resource="#_a7f1d8de-d658-428a-821b-3a5ae5965fd1"
622 />
623   <cim:Conductor.length>22</cim:Conductor.length>
624   ...
625   <cim:IdentifiedObject.mRID>17086487-56ba-4979-b8de-
626 064025a6b4da</cim:IdentifiedObject.mRID>
627 </cim:ACLineSegment>
```

628 In general RDF/XML allows further abbreviating IRIs (Internationalized Resource Identifier¹) in
629 XML attributes in two ways. The XML infoset provides a base URI attribute xml:base that sets
630 the base URI for resolving relative IRIs, otherwise the base URI is that of the document. The
631 base URI applies to all RDF/XML attributes that deal with IRIs which are rdf:about, rdf:resource,
632 rdf:ID and rdf:datatype. The rdf:ID attribute on a node element (not property element, that has
633 another meaning) can be used instead of rdf:about and gives a relative IRI equivalent to "#"
634 (i.e. denotes URI fragment) concatenated with the rdf:ID attribute value. So for example if
635 rdf:ID="http://iec.ch/TC57/CIM100#_17086487-56ba-4979-b8de-064025a6b4da", that would be
636 equivalent to rdf:about="#_17086487-56ba-4979-b8de-064025a6b4da". rdf:ID provides an
637 additional check since the same name can only appear once in the scope of an xml:base value
638 (or document, if none is given), so is useful for defining a set of distinct, related terms relative

¹ Internationalized Resource Identifiers (IRIs) are a new protocol element, a complement to URIs [RFC2396]. An IRI is a sequence of characters from the Universal Character Set (Unicode/ISO10646). There is a mapping from IRIs to URIs, which means that IRIs can be used instead of URIs where appropriate to identify resources.

to the same IRI. Both forms require a base URI to be known, either from an in-scope xml:base or from the URI of the RDF/XML document.

In CIMXML the “#” sign also replaces the base declared by xml:base but the instance files do not include declaration of xml:base. Therefore, parsers will assign local path as xml:base and the result could be something like this rdf:ID="C:\Temp_17086487-56ba-4979-b8de-064025a6b4da".

In addition, current CIMXML exchanges separate between rdf:ID and rdf:about. rdf:ID is used when a class is created and rdf:about is used when additional instance data is added to the same entity. As stated in IEC 61970-600-1:2021, there is a proposal to change this in the future versions and only rdf:about to be used.

Same URI concept is applied to rdf:resource. Currently rdf:resource="#_a7f1d8de-d658-428a-821b-3a5ae5965fd1" is a reference to a class with rdf:ID "_a7f1d8de-d658-428a-821b-3a5ae5965fd1" or cim:IdentifiedObject.mRID "a7f1d8de-d658-428a-821b-3a5ae5965fd1" and it is assumed that this class can be found locally as there is no xml:base declared. This approach will work for linking with reference data as the identifier is part of the data for each skos:Concept class, e.g. dcterms:identifier.

However, more direct linkage can also be used and it conforms to CIMXML as the same approach is used when referring to enumerated values. An example of same ACLineSegment class is provided below where the reference to the BaseVoltage class is not abbreviated and “#” sign is not used.

```
<cim:ACLineSegment rdf:ID="_17086487-56ba-4979-b8de-064025a6b4da">
  <cim:IdentifiedObject.name>BE-Line_1</cim:IdentifiedObject.name>
  ...
  <cim:ConductingEquipment.BaseVoltage
rdf:resource="http://energy.referencedata.eu/BaseVoltage/_a7f1d8de-d658-428a-821b-
3a5ae5965fd1" />
  <cim:Conductor.length>22</cim:Conductor.length>
  ...
  <cim:IdentifiedObject.mRID>17086487-56ba-4979-b8de-
064025a6b4da</cim:IdentifiedObject.mRID>
</cim:ACLineSegment>
```

7.4 Data validation

SHACL based constraints are used for the validation of reference datasets. The constraints cover cardinality of associations and attributes, datatypes, and any other complex dependencies.

7.5 Data publication

Reference data is published under the domain²: <http://energy.referencedata.eu>. Different systems should be able to automatically retrieve the data (using APIs or other techniques) in order to keep local copies up to date.

7.6 Data serialisation

Currently CIMXML that conforms to IEC 61970-552 is used for serialisation of XML documents. The standard that is published by IEC has issues and implementation of this standard take some assumptions. Both CGMES v2.4 and CGMES v3.0 are using the same CIMXML serialisation. Note that old profiles (CGMES v3.0 and prior versions) use file header specified by IEC 61970-552, while new profile such as NC profiles use the header specified in the ENTSO-E “Metadata and document header data exchange specification”.

7.6.1 Data serialisation outlook

In general, the serialisation of reference data can follow the same CIMXML serialisation. However, many IT services are using JSON and this becomes a preferred serialisation. Therefore, community is working to clarify how JSON-LD serialisation (similar to JSON, but

² Note that there is ongoing process of data publication and not all reference data is available at this location at the time of the publication of this document.

689 adapted for linked data) should be applied to CIM and reference data related to CIM based data
690 exchanges. A separate specification will be provided to specify this. In addition, W3C
691 serialisation- Turtle is used for explanation of different approaches as this serialisation is more
692 human readable.

693 JSON-LD (A JSON-based Serialization for Linked Data, W3C Recommendation 16 July 2020)
694 is defined here: [JSON-LD 1.1 \(w3.org\)](https://www.w3.org/TR/json-ld/). Specific usage for CIM based data exchanges will be
695 defined at later stage together with a transition plan.

696 7.7 Data packaging

697 The document “Metadata and document header data exchange specification” describes the
698 header that accompanies the reference data as well as the packaging and linking the data via
699 a manifest instance file.

700 8 Implementation guidance

701 8.1 General

702 In the previous versions of boundary specification, the boundary dataset could contain only
703 non-overlapping datasets. Starting with this version, it is allowed to have CIM objects belonging
704 to a boundary dataset duplicated between the boundary dataset and the IGMs or whatever
705 applicable dataset, with following implications:

- 706 - Existing tooling is not required to be changed in the usual case of TSO-TSO merge as
707 it can still operate without duplicates. However, in cases for boundary point in
708 substation, including cross-border connection through a transformer and TSO-DSO data
709 exchanges, duplication is applied and shall be supported. In these cases, business
710 processes need to ensure transition period.
- 711 - For enabling BoundaryPoint in substation (the HVDC use case) the reference data and
712 boundary set need to be published/updated. No changes in CGMES profiles.
- 713 - When a system operator, e.g. a TSO needs to manage boundary and reference data
714 related to exchanges between the TSO and DSOs, special attention should be paid on
715 the common data such as GeographicalRegion, SubGeographicalRegion-s,
716 BaseVoltage-s, Substation-s, VoltageLevel-s, etc. Already existing reference data shall
717 be used and extended using the same concept in order to cover local needs.
- 718 - Mixing boundary and reference data should be discouraged and as reference data gets
719 published and updated different projects shall plan transition to new approaches.

720 8.2 Examples on boundary datasets and reference datasets

721 The following examples illustrate the implementation of the boundary and reference data.

722 8.2.1 Complete set which includes reference data

723 This is the current way of describing boundary information. Necessary reference data such as
724 BaseVoltage instances are included in the Equipment profile describing boundary set instance.

725 An example is available in the Test Configurations included in the CGMES Conformity
726 Assessment Scheme v3.0.

727 8.2.2 Separate boundary and reference datasets

728 In this way of exchange, the pure boundary information which relates to the boundary points
729 and their containment is separate for reference data.

730 An example is available here:
731 [https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/B](https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/BoundaryTestSample/SeparateBoundaryAndRefData.zip)
732 [oundaryTestSample/SeparateBoundaryAndRefData.zip](https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/BoundaryTestSample/SeparateBoundaryAndRefData.zip)

733

734 8.2.3 Modular boundary set per MAS border and separate reference dataset

735 In this way of exchange, the boundary dataset is split per MAS (e.g. TSO) border and the
736 reference data is separated. This gives more flexibility for system operators to reuse the borders
737 that are necessary for different merged models and local references when exchanging with
738 DSOs. In addition, it is expected that there will be improved stability of the boundary dataset
739 and change of one interconnection would not have impact on the instance data dependency of
740 a MAS that it is not making use of the changed interconnection.

741 An example is available here:
742 [https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/B](https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/BoundaryTestSample/ModularBoundaryPerMasBorderSeparateRefData.zip)
743 [oundaryTestSample/ModularBoundaryPerMasBorderSeparateRefData.zip](https://extra.entsoe.eu/Board/DC/CIM/CIM%20CGMES/BusinessProcess/Boundary/RefDoc/BoundaryTestSample/ModularBoundaryPerMasBorderSeparateRefData.zip)

744

745 9 Bibliography

- 746 • ENTSO-E Metadata and document header data exchange specification, v2.1, Sep 2022.

747

748

749

750 10 Annex A: Boundary point issue background

751 Boundary point placed in substation was designed in 2013 in CGMES 2.4.15. However, CGMES
752 2.4.15 EQBD and TPBD had issues which prevented the utilization of this. In CGMES v3.0
753 boundary point in substation was revised. Recent activities related to development of test
754 configurations for CGMES v3.0 revealed some issues.

755 IEC 61970-456 only states this: "A boundary network part may also have a Substation instead
756 of a Line as shown in Figure 10. In this case the Substation, a VoltageLevel and a
757 ConnectivityNode is in the boundary network part while the rest of the Substation equipment is
758 defined within the regional network parts."

759 In the context of CGMES v3.0 and BoundaryPoint class this means the following:

- 760 - In the Boundary MAS the following elements are defined: ConnectivityNode,
761 BoundaryPoint, VoltageLevel, Substation, SubGeographicalRegion (because there is
762 required association end Substation.Region), GeographicalRegion (because there is
763 required association end SubGeographicalRegion.Region)
- 764 - All elements that belong to MAS of an IGM are exchanged in the instance files of MAS
765 IGM 1, but are contained in regions and in Substation/VoltageLevel (for the elements
766 the boundary substation) defined in boundary MAS. The same logic for MAS IGM 2.
767 EquivalentInjection-s related to BoundaryPoint will also be contained in the respective
768 MAS.

769 Therefore, in order to model boundary point in a substation, the boundary substation and related
770 containers need to be defined in the boundary MAS in a similar way as the Line is defined in
771 Boundary MAS for a case of BoundaryPoint placed on a tie-line.

772 The use cases for boundary point in substation are:

- 773 - TSO-DSO boundaries, not only within one country/control area, but also in case of
774 cross-border connection via a transformer.

- 775 - TSO-TSO boundary in cases where the border crosses in a substation (on a
776 transformer)
- 777 - DSO-DSO and TSO-SGU and DSO-SGU, and MV – LV if they are managed by different
778 system by the utility.
- 779 - In back-to-back HVDC interconnections, where the two boundary points are placed in a
780 substation
- 781 - In detailed modelling of HVDC interconnection, where the two boundary points are
782 placed in a substation
- 783 Guidance/specification on the following points is needed:
- 784 - Vendors need to decouple GeographicalRegion (or SubGeographicalRegion) and MAS
785 concepts, i.e. it should be possible to serialize in respective MAS the equipment
786 independently of where it is contained.
- 787 - If the BoundaryPoint is in a substation the boundary substation (no matter how big it is)
788 should be part of the boundary MAS. Here some guidance should be given as people
789 need to also distinguish on asset level. It is most probably the case that MAS IGM 1 and
790 MAS IGM 2 may have its own substations that contain their assets. That looks fine at
791 the first sight, but there are rules that block e.g. switch between 2 substations.
- 792 - With this setup many elements in MAS IGM 1 that are contained in the substation
793 defined in boundary as shared container will also belong to the boundary regions. Note
794 in case of a big substation that it could also contain generation or loads. Here it is
795 important to see what explanation is needed in case there is a generator in the boundary
796 substation contained in e.g. ENTSO-E region, but exchanged in MAS IGM 1 (e.g. BE)
797 and considered as part of BE. The bigger the substation the more questions like this
798 would appear. A related question here is what role in the setup ControlArea and
799 TieFlows play here and if they would need to be treated differently in the case of
800 BoundaryPoint in a Substation
- 801 - In case of a substation busbar being designated as a boundary point there will be many
802 elements (more than 2 branches and potentially single terminal devices) connected to
803 it. Depending on what belongs to MAS IGM 1 and what to MAS IGM 2 there should be
804 a logic in the tools that the flow via elements that belong to MAS IGM 1 is summed as
805 p,q of the EquivalentInjection that would represent the flow exchange for MAS IGM 1.
806 Same for MAS IGM 2. Therefore, the logic is more complex compared to a single line
807 which ends are connected to two different regions (in case of tie line boundary).
- 808 - There should be a statement that the boundary substation cannot be defined in MAS
809 IGM 1 as this will break many other rules e.g. boundary set would be dependent on MAS
810 IGM 1, MAS IGM 2 equipment will need to point to containers in MAS IGM 1 which is
811 also forbidden. Alternative way is to allow duplications for elements that are defined in
812 a boundary set.
- 813 - Need to discuss if the association end Substation.Region should remain required or be
814 optional like the Line. Or be optional only in cases the boundary point is in substation.
815 It is not necessary that we need to touch here, but some discussion is necessary to
816 confirm.
- 817 - Some of the rules in section 5.7 in IEC 61970-600-1 may need clarification depending
818 on the discussion on this issue. At the first sight it seems there is no controversial things,
819 but some of the figures there may confusing.
- 820 - With the fact that potentially many elements will be part of the boundary substation that
821 is not part of MAS IGM 1. The reporting on flows and other statistics between regions,

822 sub regions, substations might be somewhat complicated. Some guidance is needed
823 here to suggest some directions.
824
825
826